

BAFANG

EN



BAFANG

Suzhou Bafang Electric Motor
Science-Technology Co., Ltd
No.9 Heshun Rd
Suzhou Industrial Park
215122, Suzhou China
bf@szbaf.com
www.szbaf.com

DEALER MANUAL

HD Drive System

CONTENT

Important Notice	4	4.4 Battery Health Indication	41
For your Safety	5	4.5 Battery Installation.....	42
Note	6	5 Display (DP C10.UART)	43
1 Drive Unit (MM G32.1000)	7	6.1 Specifications and Parameters of the Display	43
1.1 Advantages.....	7	6.2 Appearance and Dimensions	43
1.2 Scope of Application.....	7	6.3 Function Overview and Key Definitions	44
1.3 Product Naming Protocol	7	6.4 Normal Operation	46
1.4 Main Technical Parameters	8	6.5 Parameter Setting	48
1.5 Drive Unit Structure and Dimensions	9	6.6 Error Code Definitions	55
2 System Installation.....	10	6 List of Materials	56
2.1 List of Tools to be used	10	7.1 Display Unit-DP C10.UART	56
2.2 Component Names	11	7.2 Drive Unit -MM G32.1000	56
2.3 Display Installation (DP C10.UART)	12	7.3 Cables.....	58
2.4 Auxiliary Keypad Installation	13	7 Service and Warranty Policy.....	59
2.5 Battery Rail Installation.....	15	Notes.....	60
2.6 External Speed Sensor Installation SR SD02.01	15		
2.7 Drive Unit Installation	18		
3 System Cabling.....	25		
3.1 Connection of the Battery Cable to the Drive unit	25		
3.2 Connection of the Speed Sensor to the Drive unit	25		
3.3 Connection of the EB-BUS to the Drive unit	26		
3.4 Connection of the Headlight Cable to the Drive Unit.....	26		
3.5 Connection of the Headlight to the Drive Unit	27		
4 Battery (Optional)	39		
4.1 Using the Battery Properly	40		
4.2 Charging the Battery.....	40		
4.3 Battery Capacity Display	41		

IMPORTANT NOTICE

- To avoid any harms to riders, before assemble the HD motor you must confirm that the bike frame has high mechanical intensity.
- The Dealer Manual is to be used by professional e-bike mechanics. Dealers who have not received training on electric bicycle assembly shall not attempt to assemble parts and components by following the Dealer Manual.
- If in doubt about any part of the manual, do not attempt to install the product. Please consult the local sales office or an electric bicycle dealer for help.
- Make sure you read all of the installation manuals delivered with the product.
- Do not disassemble or modify the product unless specified by the Dealer Manual.
- The Dealer Manual is available on our website (www.szbf.com).
- The dealer shall observe the laws and regulations of the region, the state and the country where the product is sold.

Make sure you have read this Dealer Manual carefully in order to use the product properly.

FOR YOUR SAFETY

When installing this product, be sure to follow the instructions given in the manual!

It is recommended that you use only genuine BAFANG parts at all times. Serious injury may result if loose or faulty bolts and nuts suddenly come off.

If the product is improperly adjusted, accidents and serious injury can occur.

- When performing maintenance operations (for example parts replacement), be sure to wear goggles or eye protection.
- Please refer to the website www.szbafe.com or contact the dealer for information on the product not covered by this manual.
- Keep this Dealer Manual in a safe place for later reference.

Inform the purchaser about the following issues:

- Giving too much of your attention to the e-bike display while riding can lead to an accident.
- It is important to check that the wheels are properly attached to the bicycle before commencing riding. If the wheels are not securely attached fixed serious injury may result.
- When riding a pedal-assisted electric bicycle, you should be fully familiar with the starting-off characteristics of the e-bike before riding it. If the e-bike starts off suddenly, accidents may result.
- It is important to turn on the lights when riding in the evening and at night.

Instructions on e-bike installation and maintenance

- When cabling the product or installing the parts onto the e-bike, be sure to disconnect the battery. Not doing so may result in electric shock.
- When installing this product, be sure to follow the instructions given in the manual. If bolts and nuts are not tightened correctly or if the product is damaged, the e-bike may suddenly fall over and serious injury may result.
- The frequency of maintenance will vary depending on the usage of the e-bike. The chain should be cleaned periodically using an appropriate chain cleaner. Do not use alkaline or acidic cleaning agents to remove rust under any circumstances. If such cleaning agents are used, they may damage the chain and serious injury may result.

NOTE

Important information for the purchaser:

- Please follow instructions given in the manual for your riding safety.
 - Examine the battery charger regularly for damage, especially the cable, plug and housing. If the battery charger is damaged, it must not be used until it has been repaired.
 - Please follow the guidance given by the safety supervisor or the instructions indicated in the manual when using the product. This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or persons lacking experience and knowledge in using the product.
 - Do not allow children to play near the product.
 - Please consult the nearest dealer for any errors or problems.
 - Do not modify the system. Doing so may lead to malfunction of the system.
 - For information on product installation and adjustment, please consult your dealer.
 - The product is designed to be fully waterproof to withstand wet weather riding conditions. However, do not deliberately immerse it in water.
 - Do not clean the bicycle with a high-pressure water spray. If water gets into any of the components, operation problems or rusting may result.
 - When transporting the product on a car in wet weather, remove the battery and put it in a safe place to stop it from getting wet due to the rain.
 - Handle the product carefully and avoid subjecting it to any strong shocks.
- Some important information given in this manual may also be found on the product labels.
 - When buying a spare key for the battery, be sure to provide the number on the battery key. Please write down the number and keep it in a safe place.
 - Use a wrung-out damp cloth to clean the battery and the plastic housing.
 - For any questions regarding the maintenance and use of the product, please contact your dealer.
 - Normal wear and tear due to normal use and aging is not within our scope of quality guarantee.
 - Please contact the seller for software updates. The newest information on software is available on the official Bafang website: www.szbf.com.

1 DRIVE UNIT (MM G32.1000)

1.1 Advantages

- Use of pedal-assist speed measurement and wheel-speed measurement; the system has a dual feedback protection of the speed signals to ensure safety and reliability of the system
- High starting torque, maximum torque of more than 160 N.m, especially suitable for hill climbing
- High efficiency, low power consumption
- Low noise, smooth operation

1.2 Scope of Application

The drive unit works properly in the following environmental conditions:

- Ambient temperature: -20 to + 55°C ;
- Relative humidity: 15-95 % RH;

i The function of the product is impaired by the presence of any major caustic gas, any medium that affects the product's electrical insulation properties or any high-intensity magnetic field.

1.3 Product Naming Protocol

There is a badge on the housing, showing information as follows:




- A** MM G32.1000 Name of the drive unit
- B** 1501 Date of production, January 2015 in this example; 0001 Production serial number, ranging from 0000 to 9999; 0001 is the production serial number of the first motor
- C** 48V Rated voltage suitable for 36V drive systems
- D** 1000 W Rated motor power

1.4 Main Technical Parameters

Rated voltage (DCV)	36	/	48
Rated power (W)	750	/	750 1000 1250
Rated efficiency (%)	≥80%		
Rated rotating speed (rpm)	130~150		
Maximum torque (N.m)	≥160		
Chain wheel	46T		
Optional chain guard	full chain guard / P-shaped chain guard		
Weight (Kg)	3.9		
Sensors	pedal assist speed sensor, and bicycle wheel speed sensor and temperature sensor		
Noise (dB)	<55		
Working environment	-20° C~55° C		
Dust-proof/ water-proof grade	IP65		
Certification	CE/ UL / ROHS / EN14764		
Functions	Light function: DC 500mA/6V headlight & rearlight		







1.5 Drive Unit Structure and Dimensions




Dimension A	215mm
Dimension B	φ 210mm (46T)
Dimension C	123mm
Dimension D	68 / 100 / 110 / 120mm
Dimension E	175/190/200/210mm
Dimension F	50 / 65 / 70 / 75mm
Dimension G	88 / 103 / 108 / 113mm

2 SYSTEM INSTALLATION


2.1 List of Tools to be used

Components	Use of the Tools	Tools
Display	To tighten M3 & M4 screws	 Internal hex wrench
Drive Unit	To fasten M6 & M8 & M33 bolts and nuts onto the frame adapter and the drive unit	 Internal hexagonal wrench and two dedicated tools
	To fasten M8 screws on the crank mounting	 Internal hexagonal wrench
Speed Sensor	To install the iron magnet	 Straight slot screwdriver
	To tighten M5 screws of the speed sensor	 Phillips screwdriver
Battery	Optional	 Internal hex wrench


Delicated tools 1 for bottom bracket and drive unit assembly



Delicated tools 2 for bottom bracket and drive unit assembly




2.2 Component Names




- A Drive unit
- B Front chain wheel
- C External speed sensor
- D Battery(Optional)
- E Auxiliary keypad
- F Display

2.3 Display Installation (DP C10.UART)




- Ⓐ Rubber clamping ring
Left and right display clamps for the $\varnothing 22.2$ handlebar:
Left and right display clamps for the $\varnothing 25.4$ handlebar:

One or two rubber clamping rings may be needed depending on the diameter of the handlebar (the applicable handlebar specifications are $\varnothing 22.2$, $\varnothing 25.4$ and $\varnothing 31.8$).
Open the left or right display clamp, and insert one or two clamping rings into the right position of the display clamp as shown in the picture above.




- Ⓑ display clamp
- Ⓒ hex socket head cap screws M4×8

Insert the clamping ring(s) to each of the two display clamps and mount them onto the handlebar. Use an internal hex wrench to fasten the left and right clamps onto the handlebar.




Adjust the angle of the display so that you can easily see the display screen when riding. After the angle has been adjusted, tighten the screws to the specified torque.
Tightening torque: 1 N.m

2.4 Auxiliary Keypad Installation




A keypad clamp

Open the auxiliary keypad and assemble it onto a position that is easy for operation. Adjust the angle of the auxiliary keypad to ensure that the keypad is easy to see during riding.
(Applicable to the handlebar whose external diameter is $\varnothing 22.2\text{mm}$)



- B** hex socket head cap screw M3×8


Fix the keypad onto the handlebar with a screw. Then tighten the fixing screw with an internal hex wrench.
Tightening torque:1 N.m



- H** female connector at the display
h male connector at the EB-BUS

Match the female connector at the display with the male connector at the EB-BUS as shown in the picture above.

2.5 Battery Rail Installation




Align the mounting holes of the carrier with the mounting holes of the battery rail. Fasten the battery rail onto the battery carrier with hex socket head screws (M5).

Tightening torque: 2 N.m


Choosing a corresponding battery and under the help of professional mechanics or local dealers to assemble it.

2.6 External Speed Sensor Installation S R SD02.01



- A external speed sensor
- B magnet unit
- C spoke
- D cable of speed sensor
- E chain stay

Before installing the speed sensor, please make sure the gap between the speed sensor and the magnetic unit is between 3 and 5 mm.




- A external speed sensor
- B cable ties


If the gap is within the specified range, use the mounting bolt to fix the speed sensor.

If the gap is more than 25 mm, please put spacers between the sensor and the chain stay boss to reduce this gap.

Tightening torque: 1.5-2 N.m





Arrange the speed sensor and the magnet unit as shown in the picture above. When installing the magnet unit, make sure its center is aligned with the center of the speed sensor's induction zone.



- A external speed sensor
- B magnet unit
- C spoke


Arrange the speed sensor and the magnet unit as shown by the picture above. Mount the magnet unit onto the spoke.



-  D Mounting nut of the magnet


Tighten up the mounting nut with a straight slot screwdriver. Tightening torque: 1.5-2 N.m

2.7 Drive Unit Installation



- Ⓐ battery cable
- Ⓑ EB-BUS
- Ⓒ external speed sensor cable


Cables should be arranged in advance according to the e-bike type and the cabling system before installing the drive unit.



- Ⓐ chain wheel
- Ⓑ 5-M5 screw

Assemble the drive unit from right side of bike frame into bottom bracket.


i Pay attention to the outgoing directions of the cables. Please note that the cables should not be squeezed by the drive unit.



A bottom bracket

B drive unit

Dedicated bottom bracket internal hole, machining it to $\Phi 33.6\text{mm}$
 Assemble the drive unit from right side of bike frame into bottom bracket.




A fixed holder

B 2-M6 screw


C M8 screw(dedicated BB)

Put the fixed holder on the bottom bracket. Fasten it with M6 screw. Tightening torque: 10 N.m
 Dedicated: fasten it with M8 screw. Tightening torque: 20 N.m




A M33 steel nut

Fasten the dedicated M33 steel nut required torque. Tightening torque: 50 N.m



A M33 aluminum nut

Fasten the dedicated M33 aluminum nut tool to required torque. Tightening torque: 25 N.m




A M8*15 screw

B L/R crank

Assemble the R/L cranks on the main shaft. Lock it with M8 screw. Tightening torque: 35-40 N.m

3 SYSTEM CABLING


3.1 Connection of the Battery Cable to the Drive Unit



- A female connector for the positive cable at the battery(optional)
- a male connector for the negative cable at the drive unit(optional)

The power bus, which is made up of a positive battery cable, a negative battery cable and battery communication cables(optional), is connected to the battery cables at the drive unit.


3.2 Connection of the Speed Sensor to the Drive Unit



- B male connector at the speed sensor
- b female connector at the drive unit for connection to the speed sensor

Link the male connector at the external speed-detecting sensor to the female connector for the external speed-detecting sensor cable at the drive unit.


3.3 Connection of the EB-BUS to the Drive Unit



- Ⓒ male connector at the EB-BUS
- Ⓒ female connector at the drive unit for connection to the EB-BUS

Link the EB-BUS cable to the EB-BUS connector at the drive unit.


3.4 Connection of the Headlight Cable to the Drive Unit(Optional)



- Ⓓ female connector at the headlight cable
- Ⓓ male connector for the headlight at the drive unit

Link the headlight cable to the connector for the headlight at the drive unit.

3.5 Connection of the Headlight to the Drive Unit



- Ⓔ female connector at the headlight cable
- Ⓕ male connector for the headlight at the drive unit

Link the headlight cable to the connector at the drive unit.

4 BATTERY (OPTIONAL)

Precautions

- If any liquid leaking from the battery gets into your eyes, rinse immediately with clean water (e.g. tap water). Seek medical advice immediately; otherwise the battery liquid may damage your eyes.
- Do not recharge the battery in places with high humidity or outdoors. Doing so may result in electric shock.
- Do not insert the plug while it is wet. Plug and socket need to be dry, otherwise electric shocks may result.
- If the battery does not become fully charged after 6 hours, unplug the battery from the outlet immediately and stop charging. Not doing so may cause overheating, rupture, or ignition of the battery.
- Do not use the battery if it has any noticeable damage. Doing so may cause rupture, overheating or malfunction.
- The battery may only be used in the temperature ranges states below. Do not use the battery in temperatures outside these ranges. If the battery is used or stored in temperatures outside these ranges, fire, injury or malfunction may occur.
 1. Temperature for discharging: -10°C to 50°C
 2. Temperature for charging: 0°C to 40°C

Danger

- Do not deform, modify or disassemble the battery. Do not apply solder directly to the battery. Doing so may cause leakage, overheating, rupture or ignition of the battery.
- Do not leave the battery near sources of heat (e.g. heaters). Do not heat the battery or throw it into a fire. Doing so may cause rupture or ignition of the battery.
- Do not subject the battery to strong shocks or throw it. If this is not observed, overheating, rupture or ignition of the battery may occur.
- Do not immerse the battery into fresh water or seawater, and do not allow the battery terminals to get wet. Doing so may cause overheating, rupture or ignition of the battery.
- Only use the specified charger. Not doing so may cause overheating, bursting, or ignition of the battery. Observe the components during the specified charging conditions when charging the battery.
- Do not short-circuit the discharge port with metal, or else it may cause overheating, rupture or ignition of the battery.
- Do not leave the battery in a place exposed to direct sunlight, inside a vehicle on a hot day or in other hot places. Doing so may result in battery leakage.
- If any leaked fluid gets on your skin or clothes, wash it off immediately with clean water. The leaked fluid may damage your skin.
- Store the battery in a safe place out of the reach of children and pets.

4.1 Using the Battery Properly


The battery can be charged at any time no matter how much power is left. However, in the following cases, the battery needs to be fully charged. Make sure you use the specified charger to charge the battery.

- The battery is usually not fully charged for the convenience of transport. Make sure the battery is fully charged before using the battery.
- If it is not intended to use the battery for a long time, make sure the e-bike battery is charged before storage and that is charged at least once every twelve months thereafter. Do not leave the battery completely discharged.
- Once you have begun to use the battery, please have it charged at least once every two weeks.

i If the battery is completely discharged, charge it as soon as possible. If you do not charge the battery, it will be damaged.

4.2 Charging the Battery

- When using the battery for the first time, check that the battery has not run low in transport or storage.
- If it not intended to use the battery for a long time, charge the battery regularly to avoid excessive battery discharge.
- Please charge the battery as soon as possible before it runs out; over-discharge can cause permanent damage to the battery.
- No matter how much power is left, the battery can be charged at any time. However, the specified charger must be used to avoid overcharge of the battery.



6 DISPLAY (DP C10.UART)


6.1 Specifications and Parameters of the Display

- 36V / 48V Power Supply
- Rated Current: 10mA
- Maximum Operating Current: 30mA
- Power-off Leakage Current: <1uA
- Operating Current Supplied to the Controller: 50 mA
- OperationTemperature: -18~60 %
- StorageTemperature: -30~70 %
- Waterproof Grade: IP65
- Storage Humidity: 30 % – 70 %

6.2 Appearance and Dimensions

6.2.1 Materials and Dimensions

- The shell is made of PC. The liquid crystal display is made of hardened PMMA.




6.3 Function Overview and Key Definitions

6.3.1 Function Overview

- Use of a two-way serial communication protocol, simple operation of the display via the external 5-key keypad.
- Speed display: displaying the real-time speed as SPEED, the maximum speed as MAXS and the average speed as AVG.
- km or mile: The user can choose between km and mile.
- Intelligent battery level indication: With an optimization algorithm, a stable display of the battery level is ensured, and the problem of fluctuant battery level indication common with other displays is avoided.
- Automatic light-sensitive lights: The headlight, taillight and display light will be automatically turned on/ off depending on lighting conditions.
- 5 levels off display backlighting: Different levels
- 5-Level-Support: setting power Levels 1 to 5
- Trip distance indication: The maximum distance displayed is 99999. Single-trip distances TRIP or the total distance TOTAL can be displayed.
- Display of error messages
- Walk assistance
- Settings: Various parameters, e.g. mode, wheel diameter, speed limit etc., can be set on the computer via a communication cable. See the setting
- Maintenance warning (this function can be deactivated): Maintenance warning information is displayed based on battery charge cycles and riding distance. The display automatically estimates the battery life and gives warnings when the number of charge cycles exceeds the set value. A warning will also be displayed when the accumulated total riding distance exceeds the set value.


6.3.2 Information on the Display



- (A) Maintenance warning: When there is a need for maintenance the symbol **SERVICE** will be displayed (riding distance or the number of battery charge cycles exceed the set value, function can be deactivated)
- (B) Menu
- (C) Speed display: display of the speed, km/h or mph
- (D) Speed mode: average speed (AVG km/h), maximum speed (MAXS km/h)
- (E) Error display: When a fault is detected the symbol **Y** will be displayed.
- (F) Distance indication: display of the distance depending on the setting.
- (G) Level indication: The chosen level 1 – 5 will be displayed; if there is no numeric display, it means that there is no assistance (by the motor). If the rider is walking and pushing the e-bike, **WALK** will be displayed.
- (H) Walk assistance
- (I) Headlight indication: only shows when headlight or backlight are on

- J Distance mode: display of the single-trip distance TRIP and the total distance TOTAL
- K Battery level: 10-segment battery indication; the voltage that each segment represents can be customized



6.3.3 Key Definitions





- A up
- B down
- C headlight
- D on/off
- E mode


6.4 Normal Operation

6.4.1 On/Off Switch

Turn on the device. Press and hold  for 2 seconds to power on the display. Press and hold  again for 2 seconds to power off the display. If the bike is not used, after 5 minutes (time can be set) the display will be automatically turned off.


6.4.2 Assist Mode Selection


In the manual gearshift mode, press the  or  to choose the desired level of support by the motor. The lowest level is Level 1, the highest Level 5. When the display is on, the default mode is Level 1. When there is no numeric mode display, there is no power assistance.



Selecting the level for motor assistance



6.4.3 Switch between Distance Mode and Speed Mode


Briefly press  to switch between distance and speed. Single-trip distance (TRIP km) → total distance (TOTAL km) → maximum speed (MAXS km/h) → average riding speed (AVG km/h) are displayed in successive order.



Switching between displays

6.4.4 Headlight/ Display Backlight Switch



Press  for 2 seconds. The backlight of the display as well as the headlight and taillight will be turned on. Press  again for 2 seconds to power off the display backlight/headlight/taillight. (If the display is turned on in a dark environment, the display backlight/headlight/taillight will be turned on automatically. If the display backlight/headlight/taillight are turned off manually, they also need to be turned on manually afterwards).




Display backlight, headlight and taillight

There are 5 levels of backlight brightness that can be selected by the user.

6.4.5 Walk Assistance


Press  for 2 seconds. The e-bike enters the walk assistance mode, and the symbol WALK is displayed. Once the key  is released, the e-bike will exit the walk assistance mode.



Switch between power assistance and walk assistance mode

6.4.6 Battery Status Indication

When the battery status is normal, a certain number of the battery LCD segments as well as the border light up according to the actual quantity of charge. If all of the 10 segments will black out with the border blinking, the battery needs to be charged immediately.



Battery status indication

Number of Segments	Charge in Percentage	Number of Segments	Charge in Percentage	Number of Segments	Charge in Percentage
10	≥90%	6	50% ≤C < 60%	2	15% ≤C < 25%
9	80% ≤C < 90%	5	45% ≤C < 50%	1	5% ≤C < 15%
8	70% ≤C < 80%	4	35% ≤C < 45%	border blinking	C < 5%
7	60% ≤C < 70%	3	25% ≤C < 35%		


6.5 Parameter Setting

6.5.1 Items to be Set:

- 1 > Data reset
- 2 > km/mile
- 3 > Light sensitivity
- 4 > Display backlight brightness
- 5 > Automatic off time
- 6 > Maintenance warning settings
- 7 > Input of the password
- 8 > Wheel diameter selection
- 9 > Setting speed limit

6.5.2 Setting Preparation

When the display is active, press **i** twice (interval < 0.3 seconds). The system will enter the MENU parameter setting state, in which the display parameters can be set. Press **i** twice again (interval < 0.3 seconds) to return to the main menu.



Menu for entering the parameter settings


In the parameter setting state, when the parameter you want to set begins to flash, press **+** / **-** to adjust the parameter value. Briefly press **i** to switch between the parameters to be set. Press **i** twice (interval < 0.3 seconds) to exit the submenu.

If no operation is performed for 10 seconds, the display will return to the normal riding display.

6.5.3 Data Reset

Press **i** twice (interval < 0.3 seconds) – the display enters the MENU state. In the speed field tC is displayed. If you press **+**, a y is also displayed. Now all temporary data, e.g. maximum speed (MAXS), average speed (AVG) and single-trip distance (RIP) can be cleared. Briefly press **i** (< 0.3 seconds) to enter the km/mile setting interface.

If the user does not reset the data, the single trip distance and the accumulated total riding time will be automatically cleared when the accumulated total riding time exceeds 99 hours and 59 minutes.




The data will not be cleared when the display's light-sensing function is set to 0 or when it is switched off.

6.5.4 km/mile

When the speed field displays S7, press **+** / **-** to switch between km/h and mph, or to set km or mile.

After this setting, briefly press **i** (< 0.3 seconds) to enter the setting interface of light sensitivity.



6.5.5 Light Sensitivity

When the speed field displays bL0, use **+** / **-** to choose a figure between 0 and 5. The higher the chosen figure, the higher the light sensitivity.

After this setting, briefly press **i** (< 0.3 seconds) to enter the setting interface of backlight brightness.



6.5.6 Display Backlight Brightness

When the speed field displays bL1, press **+** / **-** to choose a figure between 1 and 5. The figure 1 represents the lowest brightness while 5 indicates the highest display backlight brightness.

After this setting, briefly press **i** (< 0.3 seconds) to enter the setting interface of automatic off time.




to

6.5.7 Automatic Off Time

When the speed field displays OFF, press **+**/**-** choose a figure between 1 and 9. The figures indicate the minutes that it takes to automatically shut down the display.


After this setting, briefly press **i** (< 0.3 seconds) to enter the setting interface of maintenance warning.



6.5.8 Maintenance Warning (can be deactivated)

When the speed field displays nna, press **+**/**-** to choose either 0 or 1. 0 disables the function while 1 enables it.

After this setting, briefly press **i** (< 0.3 seconds) to enter the setting interface of password input.



Maintenance Warning Setting

The display will prompt maintenance necessity based on such information as the accumulated riding distance and the battery charge cycles.

- When the accumulated total riding distance exceeds 5,000 km (can be customized by the manufacturer), the display will show the symbol **SERVICE**. When the display is started up, the sign for accumulated riding distance will flash for 4 seconds, indicating that maintenance is necessary.
- When the number of battery charge cycles exceeds 100 (can be customized by the manufacturer), the display will show the symbol **SERVICE**. When the display is started up, the sign for

battery will flash for 4 seconds, indicating that maintenance is necessary.

- The maintenance alert function can be disabled: settings→ maintenance alert (MA)→ maintenance alert (MA)→ 0. (Maintenance alert can also be set via a computer. This requires a USB connection. See also the parameter setting instructions).

6.5.9 Further Settings: Password Setting

When the speed field displays PSd, it is a prompt to enter a password. Press **+**/**-** to set the four-figure password (using digits 0 to 9). Briefly press **i** to switch between the single digits of the password. default password is "0512". Briefly press to switch between the single digits of the password. The default password is "0512". Briefly press **i** to confirm your setting. If the set password is wrong, the system automatically returns to the previous interface. If the set password is correct, the system will switch to the setting of the wheel diameter.



6.5.10 Wheel Diameter Selection


When the speed position displays Wd, press **+** / **-** to select the correct wheel diameter: 16/18/20 / 22/24/26, 700c, 28/29. The measurements are in inches. A wrong wheel diameter can lead to speed anomalies.

After this setting, briefly press **i** (< 0.3 seconds) to enter the setting interface of speed limit.



5.5.11 Speed Limit Setting

When the speed field displays SPL, the distance field displays the value of the speed limit. Press **+**/**-** **i** (< 0.3 seconds) to enter the menu of battery communication.



5.5.12 Battery Communication

The speed field displays b01 and the distance field displays the speed limit. Press **i** (< 0.3 seconds) to see the other information in sequence. After this setting, press **i** twice (< 0.3 seconds) to exit the menu.


- Only when communication has been established between the battery and the controller the following information will be displayed, otherwise the display will only show "----".



5.5.13 Information on the battery menu

Information Displayed in the Speed Field	Explanation
b01	current temperature
b02	maximum temperature
b03	lowest temperature
b04	total voltage
b05	current
b06	average current
b07	remaining capacity
b08	full capacity
b09	relative state of charge
b10	absolute state of charge
b11	charge/discharge cycle
b12	longest period without charge
b13	period since last charge
d01	voltage cell 1
d02	voltage cell 1
.....
dn	voltage cell n

5.6 Error Code Definitions

The MAX-C966 display can show e-bike faults. When a fault is detected, the icon  will be displayed. In the speed field one of the following error codes will be displayed:

Error Code	Error Description	Error-shooting Method
"03"	Brake enabled	Check whether a brake cable is stuck
"04"	The throttle has not returned home	Check if throttle has returned home
"05"	Throttle fault	Check the throttle
"06"	Low voltage protection	Check the battery voltage
"07"	Overvoltage protection	Check the battery voltage
"08"	Motor hall signal cable fault	Check the motor module
"09"	Motor phase cable fault	Check the motor module
"10"	The motor temperature has reached the threshold.	Stop the bicycle until the error code "10" disappears from the screen.
"11"	Controller temperature sensor failure	Check the controller
"12"	Current sensor failure	Check the controller
"13"	Battery temperature fault	Check the battery
"21"	Speed sensor fault	Check installation position of speed sensor
"22"	BMS communication fault	Replace the battery
"30"	Communication fault	Check the controller connection




Error display


Note: Error Code 10 will probably appear on the display when the e-bike is climbing for a long time. This indicates that the motor temperature has reached the protection value, in which case the user needs to stop the e-bike for a rest. If the user continues to run the e-bike, the motor will automatically cut off the power.

6 LIST OF MATERIALS

6.1.1 Normal Bottom Bracket



6.1.2 Dedicated Bottom Bracket



6.2 Cables

Name	Material No.	Quantity	Specification
Integrated cables		1	according to order
Speed sensor components		1	according to order
Battery cable		1	according to order
Headlight cable		1	according to order
Taillight cable		1	according to order

7 SERVICE AND WARRANTY POLICY

Suzhou Bafang Motor Science-Technology Co., Ltd (hereinafter referred to as the BAFANG) guarantees: During the warranty period, BAFANG gives warranty for products bought from BAFANG or dealers, as long as the reclamation concerns quality defects caused by the material or manufacture. (This only applies to BAFANG complete drive systems; BAFANG component parts are not covered by the warranty.)

Warranty Period and Scope

The warranty period starts from the date of leaving factory. It is 30 months for motors, and 18 months for controllers, displays, sensors and other electrical components.

The following faults are not covered by the warranty:

- Damage, failure and/or loss caused by refitting, neglect or improper maintenance, use for competition or commercial purposes; incorrect or improper use or accidents
- Damage, failure and/or loss due to transport by the purchaser
- Damage, failure and/or loss on/of the product caused by improper installation, adjustment or repair
- Damage, failure and/or loss not caused by the material or manufacture, but by incorrect use by the purchaser
- Damage, failure and/or loss to the exterior of the product that does not affect its function
- Damage, failure and/or loss caused by repair or installation undertaken by repair bases or dealers unauthorized by BAFANG
- Damage, failure or loss caused by normal wear and tear

BAFANG reserves the right to repair or replace faulty components, and is only obliged to repair or replace them.

If bike manufacturers or dealers encounter quality issues when using or selling BAFANG products, they can report the purchase order number and serial number of the product to BAFANG service department. who will check whether the products are under warranty or not. For products under warranty, BAFANG will provide free repair or give a replacement. If a repair is necessary after the expiry of the warranty period, BAFANG will invoice component parts, labor cost and shipping. If the BAFANG system needs repairing on a bike, please contact the bike manufacturer or dealer directly.

If this warranty statement is against a current law at the place of business of the dealer, the legislation currently in force shall prevail. BAFANG reserves the right to modify the terms without prior announcement.

For more information, please visit the company website: www.szbaf.com